

Thank you for purchasing the MODWAY Chair!

Before you start, here are some helpful advice:

- 1. We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
- 2. Owing to the size and weight of the chair, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 30 minutes.
- 3. Please do not use any tools other than those provided or recommended in these instructions.
- 4. Please do not throw away any of the packaging or the instruction until you have checked all the components and hardware and the furniture is fully assembled. Please ensure that the packaging is disposed of in a safe and environmentally friendly way.
- 5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
- 6. Please keep all pieces out of reach of children.



#### Hardware:


A. (a) Bolt M8x30mm x12

B. Spring Washer M8 x12

C. C Flat Washer M8 x12

D. Allen Wrench x1

# Components:




- 1. Chair Body x1
- 2. Leg x4




### STEP 1:


- 1. Please put Chair Body (1) upside down on a carpeted or padded surface.
- 2. Open the zipper on the bottom of the **Chair Body (1)** and take out the 4 pieces of **Legs (2)** and hardware package.



### STEP 2:

- 1. Attach 4 pieces of Legs (2) to the corners of Chair Body (1) by using 12 pieces of Bolts (A) with 12 pieces of Spring Washers (B) and 12 pieces of Flat Washers (C) as shown.
- 2. Use Allen Wrench (D) to tighten all Bolts (A) clockwise as shown.






Hardware & Tools Required



## STEP 3:

Close the zipper on the bottom of the Chair Body (1).



Assembly is complete. Your Chair is ready to enjoy now!