
ASSEMBLY INSTRUCTIONS

EEI-2226/2227

V1.09.28.21



Let's get started!

*modway



Read through all of the instructions before starting

Approx. 30 minutes

assembly time



Care instructions are listed in the last step of this manual



Make sure you have all parts and components before discarding any packing materials **Only use hand tools to assemble this item**. Do not use power tools. Do not tighten bolts or screws completely until all hardware is lined up and inserted into the holes.

Do not over-tighten screws and bolts to avoid stripping the hardware or cracking the item.

Assemble your item on a flat, carpeted area, with plenty of space to work. This will prevent damage and scratches to your floors or the item while you're assembling the product.

Keep all components and packaging out of reach of children or animals to avoid risk of choking or suffocation.




2 people recommended for assembly

Furniture components:

| 1 | Chair Body | х1 |
|---|------------|----|
| 2 | Chair Base | х1 |

Provided hardware:

| Α | ()mmm | Bolt M6x45mm | х4 |
|---|-------|------------------|----|
| В | | Spring Washer M6 | х4 |
| С | | Flat Washer M6 | х4 |
| D | | Allen Key | x1 |






Missing parts or hardware? Need assistance?
Contact us before returning your item. We're here to help!
609.256.9000 • cs@modway.com

Step 1

| HARI | OWARE | |
|------|------------------|-----------|
| A | Bolt M6x45mm | x4 |
| B | Spring Washer M6 | x4 |
| 0 | Flat Washer M6 | x4 |
| D | Allen Key | x1 |
| СОМ | PONENTS | |
| 0 | Chair Body | x1 |
| | | |



Great job!

Your chair is complete and ready to enjoy.

CARING FOR YOUR ITEM

Indoor use only.

Not contract grade.

Spot clean using a non-abrasive cloth and a mild cleaner.

Never use harsh chemicals, as they could damage the finish or integrity of the item.

CONNECT WITH US! (i) (i) (ii) (iii) (iii







Tag us @modway_furniture and #modway for a chance to be featured.

