


ASSEMBLY INSTRUCTIONS

EEI-5855

V1.21.03.21



Questions? Contact us!

609.256.9000 • cs@modway.com
www.modway.com

***modway**

Let's get started!

*modway



Read through all of the instructions before starting



Care instructions are listed in the last step of this manual



Approx. 30 minutes assembly time



Make sure you have all parts and components before discarding any packing materials



2 people recommended for assembly

Only use hand tools to assemble this item. Do not use power tools. Do not tighten bolts or screws completely until all hardware is lined up and inserted into the holes.


Do not over-tighten screws and bolts to avoid stripping the hardware or cracking the item.

Assemble your item on a flat, carpeted area, with plenty of space to work. This will prevent damage and scratches to your floors or the item while you're assembling the product.







Keep all components and packaging out of reach of children or animals to avoid risk of choking or suffocation.


Furniture components:

1	Backrest 1	x1	7	Seat Cushion	x1
2	Backrest 2	x1			
3	Seat	x1			
4	Back Leg	x1			
5	Front Leg	x1			
6	Back Cushion	x2			



Provided hardware:

A		Bolt M6 x 60 mm	x9	F		Connector	x1
B		Bolt M6 x 80 mm	x1				
C		Allen Key	x1				
D		Lock Washer	x10				
E		Flat Washer	x10				



Wait!

Missing parts or hardware? Need assistance?

Contact us before returning your item. We're here to help!

609.256.9000 • cs@modway.com


Step 1

HARDWARE

A	Bolt M6 x 60 mm	x3
B	Bolt M6 x 80 mm	x1
C	Allen Key	x1
D	Lock Washer	x4
E	Flat Washer	x4

COMPONENTS

1	Backrest 1	x1
2	Backrest 2	x1
3	Seat	x1




Step 2

HARDWARE

A	Bolt M6 x 60 mm	x4
C	Allen Key	x1
D	Lock Washer	x4
E	Flat Washer	x4

COMPONENTS

4	Back Leg	x1
----------	----------	----




Step 3

HARDWARE

A	Bolt M6 x 60 mm	x2
C	Allen Key	x1
D	Lock Washer	x2
E	Flat Washer	x2

COMPONENTS


5	Front Leg	x1
----------	-----------	----



Step 4

COMPONENTS

6	Back Cushion	x2
7	Seat Cushion	x1



Great job!

Your Sectional Corner assembly is complete


♥ CARING FOR YOUR ITEM

Depending on use, it may be necessary to tighten the hardware from time to time, so please save the tools that have been provided.

Not contract grade.

Clean using a non-abrasive cloth and a mild cleaner.

Retain the rich wood color by occasionally sanding lightly and applying a teak cleaner and protectant. The oils nourish and help restore the original look.




CONNECT WITH US!

Tag us **@modway_furniture** and **#modway** for a chance to be featured.

Pairing Option

COMPONENTS


- | | | |
|---|------------------|----|
| 1 | Sectional Corner | x2 |
|---|------------------|----|



Pairing Option

COMPONENTS


- | | | |
|---|-------------------|----|
| 1 | Sectional Corner | x2 |
| 2 | Sectional Armless | x1 |



Pairing Option

COMPONENTS

- | | | |
|---|------------------|----|
| 1 | Sectional Corner | x3 |
| 2 | Sectional Corner | x2 |




Pairing Option

HARDWARE

- | | | |
|---|-----------|----|
| F | Connector | x1 |
|---|-----------|----|

COMPONENTS


- | | | |
|---|------------------|----|
| 1 | Sectional Corner | x2 |
|---|------------------|----|







Thank you for purchasing the **MOD-5844/5852/5853/5854/5860/5868/5872/5880/5881/5882 FULL/QUEEN HEADBOARD** or **MOD-5845/5855/5856/5857/5861/5869/5873/5883/5884/5885 KING/CAL KING HEADBOARD**

Before you start, here are some helpful advices:

1. We suggest that you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
2. Owing to the size and weight of the bed frame, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 45 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or the instruction until you have checked all the components and hardware and the furniture is fully assembled. Please ensure that the packaging is disposed of in a safe and environmentally friendly way.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
6. Please keep all fitting out of reach of children.




Hardware list:

A		Bolt M8 x 50mm	x4
B		Spring Washer	x4
C		Flat Washer	x4
D		M5 Allen Key	x1

Component:


1) Headboard x1
(Style may vary)



2) Low Post x2

Step 1:


Put the **Headboard (1)** upside down on a carpeted or padded area by two adults. Then take out the **Low Post (2)** and **Hardware Pack** from the back side of **Headboard (1)**. Attach **Low Post (2)** to the **Headboard (1)** according to your desired headboard height. Secure each **Low Post (2)** by using 2x **Bolt (A)**, 2x **Spring Washer (B)** and 2x **Flat Washer (C)**, tighten with supplied **Allen Key (D)**, repeat the same procedure to secure the other **Low Post (2)**. Note: do not fully-tighten nuts and bolts until all nuts and bolts are partially tightened.



A x 4	B x 4	C x 4	D x 1

Step 2

Carefully turn up the assembled **Headboard (1)** by two adults.



Assembly is complete. The headboard is ready to use now!







NOTE: Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTIONS


OPTION 1

OPTION 1

Hardware list:

A		Bolt M6 x 45mm	x4
B		Bolt M6 x 65mm	x4
C		M6 Flat Washer	x8
D		M6 Spring Washer	x4
E		M6 Hex Nut	x4
F		M4 Allen Key	x1

Component:



OPTION 1

1) Headboard x1
(Style mat vary)

2) Bed Frame x1

Note: Extra screws were provided for attaching the headboard to your bed frame (use is optional).

STEP 1:

Line up the **Bed Frame (2)** board's pre-drilled holes to match those long hole of the **Headboard (1)**.


Place 1 piece of **Spring Washer (D)** and **Flat Washer (C)** on each **Bolt (A)** or **Bolt (B)**. Then fit 1 piece of **Flat Washer (C)** on the bolt as it protrudes through the other side of the **Bed Frame (2)**.



Please note **Bolt (A)** for thinner **Bed Frame (2)** and **Bolt (B)** for thicker **Bed Frame (2)**.

Secure the **Headboard (1)** to the **Bed Frame (2)** by using 2 pieces of assembled **Bolt (B)**, **Spring Washer (D)** and **Flat Washer (C)** for the thicker **Bed Frame (2)**, or 2 pieces of assembled **Bolt (A)**, **Spring Washer (D)** and **Flat Washer (C)** for the thinner **Bed Frame (2)**.

Place 1 piece of **Hex Nut (E)** after the **Flat Washer (C)** at the end of each bolt. Then tighten the **Bolts (A or B)** by using the **Allen Wrench (F)**.

Repeat the same procedure for each bolt and each side of the **Bed Frame (2)**.




				
A or B x 4	C x 4	D x 4	E x 4	F x 1

Hardware & Tool required

STEP 2:

Carefully position the assembled bed to the desired location by four adults.




Assembly is complete. The headboard is ready to use now!

NOTE: Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTIONS


Note: This is assembly instruction for Headboard connect to MODWAY Bed Frame **MOD-5347/5348/5349/5350/5351/5352/5353/5354/5581/5582/5628/5629/5616/5625/5626/5627/5357/5358/5359/5360/5361/5362/5363/5364.**

OPTION 2



Hardware list:


A



Bolt M6 x 45mm

x4


B



Bolt M6 x 65mm

x4


C



Flat Washer M6

x4


D



Spring Washer M6

x4

F




M4 Allen Key

x1

Component:

1



OPTION 2

2

1) Headboard x1
(Style may vary)

2) Bed Frame x1
(Style may vary)



STEP 1





Line up the **Bed Frame (2)** board's pre-drilled holes to match those long hole of the **Headboard (1)**.

Secure the **Headboard (1)** to the **Bed Frame (2)** by using 2 piece of **Bolts (B)** with 2 pieces of **Spring Washer (D)**, 2 piece of **Washer (C)** for the thicker **Bed Frame (2)**, or 2 piece of **Bolts (A)** with 2 piece of **Spring Washer (D)**, 2 piece of **Washer (C)** for the thinner **Bed Frame (2)**.

Then tighten the **Bolts (A or B)** by using **Allen Wrench (F)**.

Repeat the same procedure for each bolt and each side of the **Bed Frame (2)**.




			
A or B x 4	C x 4	D x 4	F x 1

Hardware & Tool required

STEP 2:

Carefully position the assembled bed to the desired location by four adults.



Assembly is complete. The headboard is ready to use now!

NOTE: Hardware may loosen over time. Periodically check that all connections are tight.