


MOD-6045, MOD-6046








Thank you for purchasing the **MODWAY BED !**

Before you start, here are some helpful advice:

1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Owing to the size and weight of the bed, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 20 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or the instruction until you have checked all the components and hardware and the furniture is fully assembled.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
6. Please keep all small pieces out of reach of children.




Hardware:

A		JCBC BOLT M6 x 40	9 PCS
B		JCBB BOLT M8 x 25	8 PCS
C		WOOD SCREW M4 X 32mm	6 PCS
D		ADJUSTER	3 PCS
E		ALLEN KEY (BALL SHAPE) M4	1 PC
F		ALLEN KEY M5	1 PC
G		FLAT WASHER	8 PCS
H		SPRING WASHER	8 PCS


Compenents :





1 -	HEADBOARD	x 1
2 -	FOOTBOARD	x 1
3 -	SIDERAIL	x 2
4 -	CENTER SUPPORT	x 1
5 -	SUPPORT LEG	x 3
6 -	SUPPORT BAR	x 2
7 -	BED SLAT	x 13



STEP 1:


Place **Headboard (1)** , **Footboard (2)** and **Siderail (3)** on a carpeted or padded area as shown. Attach **Side rail (3)** into **Headboard (1)** and **Footboard (2)** by inserting **Flat Washer (G)**, **Spring washer(H)** and **JCBB 25mm Bolt (B)** into the holes of **Headboard (1)** and **Footboard(2)**. Tighten with **M5 Allen Key (F)**.






			
Bx8	Gx8	Fx1	Hx8

Hardware & Tool required
STEP 2:

1. Attach the **Support Bar (6)** to the predrilled hole at center of **Headboard (1)** by using **JCBC bolt 40MM(A)** and tighten by using **M4 Allen Key(E)**. Repeat the same step at **Footboard(2)**, then place **Center Support bar(4)** on the **Support Bar(6)**, attach **JCBC bolt 40MM(A)** at predrill hole and tighten by using **M4 Allen Key(E)**.
2. Place the **Center Support Bar(4)** as per picture shown and attach **JCBC bolt 40MM(A)** and tighten using **M4 Allen Key(E)**. Repeat again at **Footboard(2)**
3. Attach the **Adjuster(D)** to the two **Center Support Leg(5)**.
4. Attach the **Center Support Leg(5)** to the **Center support bar(4)** as shown in diagram., Insert **JCBC 40MM (A)** to the predrilled hole and tighten by using **M4 Allen Key(E)**




		
Ax9	Dx3	Ex1


Hardware & Tool required

STEP 3:


Attach **Slat (7)** into **bed** by inserting **CSK screw (C)** into the predrilled holes on the **Slat (7)** . Tighten with **Screwdriver (Not provided)** .



Screwdriver (Not provided) .



Assembly is completed. The bed is ready to enjoy now!



Hardware & Tool required