













Thank you for purchasing the **MODWAY BED** !

Before you start, here are some helpful advice:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Owing to the size and weight of the bed, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximately assembly time:45 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or the instruction until you have checked all the components and hardware and the furniture is fully assembled. Please ensure that the packaging is disposed of in a safe environmentally friendly way.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that has been provided.
6. Please keep all fitting out of reach of children.



Hardware:

A		Bolt M8x25mm	x 20
B		Bolt M8x35mm	x 16
C		Bolt M8x50mm	x8
D		Nut M8	x8
E		Flat Washer	x 32
F		spring washer	x 16
G		Allen Wrench	x1
H		Open Wrench	x1
I		Center Plastic Cover	x13
J		End Plastic Cover	x26
K		Metal Connector	x2

Component:



P1	Headboard	x2
P2	Side Rail	x2
P3	Footboard	x1
P4	Center Rail	x1
P5	Long Support Leg	x4
P6	Leg	x4
P7	Slat	x26
P8	Black Board	x1


STEP 1:





Place **Headbaord (P1)** upside down on a carpeted or padded.

Connect two half of **Headbaord (P1)** by using 2 pieces of **Metal Connectors (K)**.

Secure by using 8 pieces of **Flat Washer (E)** and 8 pieces of **Bolts (B)** as shown .

Use **Allen Wrench (G)** to tighten **Bolts (B)** clockwise until secure.



			
B x8	G x1	E x8	k x2

Hardware & Tool required


STEP 2:




Place 1 piece of **Black Board (P8)** to the bottom edge of **Headboard (P1)** as shown .

Use 8 pieces of **Flat Washer (E)** and 8 pieces of **Bolts (C)** to connect **Black Board (P8)** from the back of assembled **Headbaord (P1)**.

Tighten **Bolts (C)** by using **Allen Wrench (G)**.

Please turn over the headboard by 2 people carefully.



		
C x8	G x1	E x8


Hardware & Tool required





STEP 3:

Attach **Legs (P6)** into **Headboard (P1)** and **Footboard (P3)** as shown.

Secure by using 8 pieces of **Flat Washer (E)** and **Bolts (A)**.

Use **Allen Wrench (G)** to tighten **Bolts (A)** tightly.



			
A x8	G x1	E x8	F x8


STEP 4:





Insert 8 pieces **Bolts (A)** into **Spring Washer (F)/Flat Washer (E)**

and the bottom holes on the **Footboard (P3)** and **Headboard (P1)**.

Leaving 0.3-0.4 inch space of the thread of **Bolts (A)** as shown for inserting the notch of **Side Rail (P2)**.

Insert the notch of **Side Rail (P2)** into the space left on the **Bolts (A)**.



			
A x8	G x1	E x8	F x8


Hardware & Tool required





STEP 5:

Attach 1 piece of **Support Legs (P5)** to **Center Rail (P4)** by using 2 pieces of **Bolts (B)** and 2 pieces of **Nuts (D)** as shown.

Use **Allen Wrench (G)** and **Open Wrench (H)** to tighten **Bolts (B)** and **Nuts (D)** until secure.

Repeat the same step for the remaining 3 pieces of **Support Legs (P5)** .



			
B x8	G x1	D x8	H x1

Hardware & Tool required


STEP 6:



Attach one end of assembled **Center Rail (P4)** to **Headboard (P1)**, and secure by using 2 pieces of **Bolts (A)** .

Repeat the same steps for **Footboard (P3)** and **Center Rail (P4)**.

Use **Allen Wrench (G)** to fix **Bolts (A)** clockwise until secure.

Tighten all **Bolts (A&B&C)** with **Allen Wrench (G)** after all assembled.





	
A x4	G x1

Hardware & Tool required

Step 7:

Insert 2 pieces of **Slat (P7)** into 2 pieces of **End Plastic Covers (J)** and 1 piece of **Center Plastic Cover (I)** as shown.

Then insert the assembled **Center Plastic Cover (I)** into the holes on **Center Rail (P4)** , and the assembled **End Plastic Cover (J)** into the holes on **Side Rail (P2)** as shown. Repeat the same steps for the remaining 24 pieces of **Slats (P7)** .

**STEP 8:**

Assembly is complete. Your bed is ready to be enjoyed now !